

1 Safety Instructions

Please carefully read all safety instructions. Klippel will not be responsible for harm resulting from disregard of any of the Safety instructions.



The assembly of the device must be done by skilled personnel.

Personnel must well understand the exact instructions given in the Assembly instructions. Through their qualification they must be familiar with risks mentioned in the instructions and avoid any danger in a thoughtful manner.



Follow the exact instructions

Ensure to follow every detail in this instruction. All Assembly steps are mandatory for proper operation of the device.



Proper Floor mounting

Ensure, that the Near field scanner is properly mounted to the floor on all 4 sides.



Do not modify the machine.

Use original cables, power supply and assembly parts only. Don not modify or repair KLIPPEL hardware or accessories without proper instruction by KLIPPEL!



Comply with the allowed weight and requirements to the set-up area

- The device must be set up in a separate room, or separated area, which can be closed to unintended access by personnel. A protective device (fence) must be installed around the measurement device, if access cannot be restricted by a separate room. (Risk of tripping and crushing)
- The workroom where the device is set up must be properly illuminated to at least 300lx. (Risk of tripping)
- A sound pressure level of 80dB should not be exceed at any nearby work area
- Set-up area must be in dry, clean indoor condition