
Scanning Rectangular Speakers

Application Note to the KLIPPEL R&D SYSTEM

Rectangular speakers are used where the space for placing loudspeakers is limited or a certain nonuniform directivity pattern shall be achieved, i.e. in flat television and display devices. The vibration and radiation properties of these speakers are more complex than for axial-symmetrical transducers. A vibration scanning measurement can help to identify the vibration modes and evaluate their influence on the sound radiation.

That Application Note gives step-by-step instructions how to perform a vibration measurement with the *Klippel Scanning System* on rectangular drivers. It gives valuable hints how to find a good setup in order to obtain optimal result data in short measurement time.



CONTENTS:

Requirements	. 2
TRF Setup	
Measurement Grid Setup	. 6
Interpretation of the Results	
More Information	

Requirements

Klippel Scanning System

The Scanning Vibrometer (SCN) performs a non-contact measurement of the mechanical vibration and the geometry data of cones, diaphragms, panels and enclosures, see SCN Specification [1].

For vibration measurements of rectangular speakers it is recommended to use a *Klippel Scanning System Version 2.0* or newer.



Features:

Measure geometry and mechanical vibration of the transducer

Visualize the vibration behavior

Show contribution to sound pressure output

Predict directivity pattern

Separate radial and circular modes

Analyze actively radiating cone regions

Detect loudspeaker defects

Start Up

To perform a scanning measurement the following equipment is required:

Install the Klippel Scanning System 2.0 software on your computer

Setup the Scanning System according to the instruction given in the Manual [2]

The setup of a new scan can be started by selecting **Perform scan...** in the **File** menu of the *Klippel Scanning System*.

After the initialization steps a new scanning project can be started. Specify a file name for the project file and **Proceed**

Start	Setup	Grid	Preparation	Scan	1
Start	Jocup	und	risparation	ocari	
	Specify project file				
	D:\Klippel\vb\visu_scan\scar	ns\AN 47.ksp			F
	Specify file used as template				
	<none></none>			•	🗃 📄
	<none></none>			•	È
	<none></none>			•	<u> </u>
	<none></none>			•	2
	<none></none>			•	
	<none></none>				<u>R</u> eset <u>Proceed</u>

TRF Setup

Perform a Test Measurement

The *Klippel TRF Module* performs the actual vibration measurement on the radiator's surface. The setup of the vibration measurement has to be adapted to the specific driver. Change the **Measurement Setup** by clicking on the Button **Edit Trf Setup**.


🖾 Scanning		\mathbf{X}
Start Setup	Grid Preparation	n Scan
Measurement Setup Laser Keyence LK-G82 Trif Preferences: Voltage Voltage 5 V rms Fmin 100 Hz Fmax 10000 Hz Resolution 46,88 Hz Shaping 9 dB/oct. Averages 64 Smoothing 30 points/oct. Log-reduce to 30 points/oct.	Scanning Method Vibration and Geometry Geometry only Scanning Mode Normal Scan Flat Scan Flat Scan Floating Scan	The normal scanning mode is recommended for most driver geometries. The scanner explores automatically the surface of the cone and avoids any physical contact with the cone while finding optimal scanning positions. This mode can be safely selected as long as there are no distinct steps larger than 20mm or steep slopes with an angle > 60°.
		Proceed

A first test measurement of the driver is advisable to find a good TRF measurement setup.

Place the speaker on the turntable and connect the clamps to the speaker terminals. For rectangular drivers it is recommended to align the longer side of the driver towards zero degree as indicated on the turntable.

Use the Motor Control device to adjust the Laser to point on a representative spot in the center of the cone. Adjust the distance of the Laser until the green OK LED indicates a valid laser signal.

Press the **Test (14)** Button in the TRF dialog to launch a vibration measurement.




Frequency Settings

The test measurement is a good starting point for improving the settings. Adopt the frequency settings now to the specific loudspeaker:

The Start Frequency **Fmin (1)** should be about 2 octaves below the resonance frequency of the driver

The End Frequency **Fmax (2)** should be as high as the expected working range of the driver

The Frequency **Resolution (3)** and the number of **Averages (4)** are good parameters for fine-tuning the signal quality of the measurement in interaction with the measurement time, see below. For the next measurement increase the Resolution (means finer resolution), i.e. **Resolution = 11Hz**




Perform another test measurement.


You can see that the signal to noise ratio (SNR) in the **Displacement Spectrum (17)** has decreased. That is due to the applied stimulus shaping. The given **Voltage (5)** input is applied at the highest frequency **Fmax (5)** and reduced towards lower frequency **Fmin (1)** according to the specified **Shaping (7)**. Because Fmax has increased now from 10kHz to 25kHz the actually applied voltage at low frequencies has decreased.

Some Keyence Laser heads will show a smaller operation range for measurements above 10kHz, please consult the Specification of the used Laser [1].

Stimulus Settings


Increase the voltage until the SNR close to the highest measurement frequency is more that at least 15dB. To improve the SNR at mid and low frequencies the **Stimulus Shaping (7)** can be reduced.





Interpretation of the Results

VibrationThe vibration analysis of rectangular cones is similar to circular cone, see also paper [5]Analysisfor detailed information.




The vibration behavior can be studied over the complete measured frequency range. Peaks in the accumulated acceleration level curve indicate distinct vibration modes.



Peaks in the quadrature component curve of the acceleration level indicate vibration modes which do not contribute to the sound pressure output at the selected observing point in the far field, especially rocking motion at lower frequencies.

A decomposition into radial and circumferential vibration components is not applicable because of the asymmetric cone shape.



More Information				
Software Documentation	 [1] Specification of the Klippel Scanning System, see <u>www.klippel.de</u> [2] Manual of the Klippel Scanning System, included in the software installation 			
Related Application Notes	[3] AN31 – Cone Vibration and Radiation Analysis			
Papers	[4] W. Klippel, J. Schlechter, "Distributed Mechanical Parameters of Loudspeakers (Part 1 Measurement), J. of Audio Eng. Soc. 57, No. 9, pp. 500-511 (2009 Sept.)			
	[5] W. Klippel, J. Schlechter, "Distributed Mechanical Parameters of Loudspeakers (Part 2 Diagnostics), J. of Audio Eng. Soc. 57, No. 9, pp. 696-708 (2009 Sept.)			

updated December 19, 2022



Klippel GmbH Mendelssohnallee 30 01309 Dresden, Germany

www.klippel.de TEL: +49-351-251 35 35 info@klippel.de FAX: +49-351-251 34 31